

NuMega Resonance Labs

Fast Reliable Services

11526 Sorrento Valley Road, Suite B-2 ♦ San Diego, CA 92121 ♦ USA
Phone 858-793-6057 ♦ Fax 858-793-2607

September 16, 2025

NuMega Reference #

2507brom.183e

Bromantane
PO box 17063
Sarasota, FL
bromantanespray@protonmail.com

Quantitative Analysis Report

Bruker 500 MHz, AVII-500 and AV-500

Sample ID	Acipimox
Standard	1,3,5-Trimethoxybenzene
Weight of Standard (wt _{st})	1.338
Weight of Sample (wt _{sa})	10.103
Assumed Sample Molecular Weight (MW _{sa})	154.12
Standard Molecular Weight (MW _{st})	168.19
Integration of Sample (I _{sa})	547.74
Integration of Standard (I _{st})	100
# of Equivalent Nuclei in Standard (n _{st})	3
# of Equivalent Nuclei in Sample (n _{sa})	2
Assigned Purity of Standard % (P)	99.83
Purity %	99.5%

Formula Used for Calculation:

$$WT\% = \frac{wt_{st}}{wt_{sa}} \times \frac{MW_{sa}}{MW_{st}} \times \frac{I_{sa}}{I_{st}} \times \frac{n_{st}}{n_{sa}} \times P$$